



#### INSTRUCTIONS

1. POSITION THE STANCHION AT THE LIVE EDGE AND ANCHOR 2 x M12 SCREWS ON THE BASE
2. PLACE THE NEXT STANCHION AT A DISTANCE OF 1.5 METRES AND ANCHOR THE BASE
3. INSERT TIMBER KICKBOARD AFTER EACH ANCHOR POINT
4. SLIDE HANDRAILS AND OVERLAP EACH SIDE BY 25CM
5. CORNERS MUST OVERLAP
6. CONTACT FOR MORE INFORMATION ON 1800 759 731

\*REFER TO YOUR STRUCTURAL ENGINEER FOR FOUNDATION REQUIREMENTS WHEN INSTALLING, SHARK SCREENS TAKE NO RESPONSIBILITY.